

TOOLBOX TALKS



M&J GROUP
CONSTRUCTION & ROOFING

1 | WORKMANSHIP - INSTALLATION OF TRIM



TEL: 0844 800 3912

EMAIL: MJ@MJCONSTRUCTIONGROUP.CO.UK

WWW.MJCONSTRUCTIONGROUP.CO.UK



M&J GROUP
CONSTRUCTION & ROOFING



TOOL BOX TALK: #11. WORKMANSHIP – INSTALLATION OF TRIM

PURPOSE OF TALK

This toolbox talk is designed to ensure all M&J operatives are upholding the technical aspect and quality that is expected throughout the whole workforce, from trainee up to fully skilled installers.

Edge trim installation is a very simple method of completing an outside edge detail over a check kerb.

If done correctly should give a secure tidy finish.

1. 30mm Screws are only to be used at 150mm centres fixed in a staggered fashion
2. Only to be screwed in and not nailed.
3. Always ensure joining straps are used.
4. Ensure external corners run in level and do not have an excessive build-up of felt underneath.
5. Always install trim on top of the underlay, making sure the underlay protrudes 10mm past the outside edge not cut flush with the outside kerb.

Although all the above is basic flat roofing, these mistakes are highlighted on a weekly basis through our ongoing training and quality control carried out by contract managers.

Remember that repeated clients new work comes from M&J quality and professionalism.



TOOL BOX TALK: #11. WORKMANSHIP – INSTALLATION OF TRIM

DO YOU HAVE ANY QUESTIONS FOR ME?

Do you have any further questions? *Ask them now & make notes here.*

Contract managers

Signature : _____ Date _____

Operatives

Name : _____ Signature _____